USB Multifunction Arbitrary Waveform Generator AWG2300

User Guide

| Safety information | |
|--|----|
| About this guide | 4 |
| AWG2300 specifications | 5 |
| Chapter 1. Product introduction | |
| 1-1. Package contents | 6. |
| 1-2. General descriptions | 6 |
| 1-3. Connectors and indicators | 7 |
| 1-4. User extension connector A | 8 |
| 1-5. User extension connector B | 9 |
| Chapter 2. PC installation | |
| 2-1. PC requirements | 10 |
| 2-2. PC installation steps | 10 |
| 2-3. "SCI AWG" software installation | 11 |
| 2-4. Driver software installation | 16 |
| Chapter 3. Instrument functions | |
| 3-1. Open communication with device | 21 |
| 3-2. Arbitrary waveform generation | 23 |
| 3-3. Analog input | 27 |
| 3-4. Digital input / output | 30 |
| 3-5. Analog output | 35 |
| Chapter 4. Programming interface | |
| 4-1. Programming requirements | |
| 4-2. Communication software example | |
| 4-3. AWG command set | 39 |
| Chapter 5. Signal expansion board | |
| 5-1. Signal expansion board | 51 |
| 5-2. Signal expansion board installation | 51 |
| 5-3. Available signals | 52 |
| Chapter 6. Mechanic drawings | |
| 6-1. AWG2300 dimensions | 53 |
| 6-2. Signal expansion board dimensions | 54 |
| Contact Information | 55 |

Contents

Safety information

Electrical Safety

- To prevent electric shock hazard, disconnect the power cable from the electric outlet before relocating the device.
- When adding or removing the device from the system, ensure that the power cables for the devices are unplugged before the signal cables are connected. If possible, disconnect all power cables from the existing system before you add a device.
- Before connecting or removing signal cables from the device, disconnect the power cables if possible.
- Seek professional assistance before using an adapter or extension cord. These devices could interrupt the grounding circuit.
- Ensure your power supply is set to the correct voltage in your area. If you are not sure about the voltage of the electrical outlet you are using, contact your local power company.
- If the power supply is broken, do not try to fix it by yourself. Contact a qualified service technician or your retailer.

Operation safety

- Before installing the instrument and adding it to your system, carefully read all the manuals that came with the package.
- Before using the product, ensure that all cables are correctly connected and the power cables are not damaged. If you detect any damage, contact your dealer immediately.
- To avoid short circuits, jeep paper clips, screws, staples and other metal parts away from connectors, slots, sockets and circuitry.
- Avoid dust, humidity and temperature extremes. Do not place the product in any area where it may become wet.
- Place the product on a stable surface.
- If you encounter technical problems with the product, contact a qualified service technician or your retailer.

About this guide

This user guide contains the information you need when installing and configuring the instrument or device.

How this guide is organized

This guide contains the following parts:

Chapter 1. Product introduction

This chapter describes the features of the instruments and functions it supports

Chapter 2. PC installation

This chapter describes the standard steps the user should follow to install the instrument on a PC running Windows operation system.

Chapter 3. Instrument Functions

This chapter demonstrates the main functions of the instrument. For first time users of this product, it is recommended that the user read or test the steps and see these working functions of the instrument.

Chapter 4. Programming Interface

This chapter provides a simple example of writing an application software to communicate with the instrument. The complete command set that is available for the user to control the instrument is also provided.

Chapter 5: Signal Expansion Board

This chapter describes how to install the signal expansion board on the instrument, to allow user access of other functional signals including digital IO, analog input and output.

More information

The SciCore Instrument website (www.scicoreinstruments.com) provides updated information on SCI hardware and software products. Refer to SCI contact information.

Specifications Summary

| Waveform Generation | |
|-----------------------------------|---|
| Channels | 2 |
| Frequency Range | DC - 50MHz |
| Sample Rate | 300 MS/s |
| Vertical Resolution | 14 bit |
| Waveform Length | 4,096 Samples/ channel |
| Amplitude | 6.0 Vpp (into 1M Ohm), |
| | 3.5 Vpp (into 50 Ohm) |
| Output Current | 50 mA |
| Output Connector | SMA (Female) |
| Standard Waveforms | Sine, Square, Pulse, Triangle, Saw-tooth, Sinc, ECG |
| Resolution | 1 mHz |
| Analog Input | |
| Channels | 8 |
| Input Range | 0 V - 3.3 V |
| A/D Resolution | 10 bit |
| A/D Conversion rate | Software controlled |
| Digital IO | |
| Channels | 8 |
| Voltage Level | 0 V - 3.3V |
| Update rate | Software controlled |
| Analog Output | |
| Channel | 4 |
| Voltage | 0 V - 4.096 V |
| D/A Resolution | 12 bit |
| D/A Conversion rate | Software controlled |
| PC Communication Interface | |
| Control Interfaces | USB |
| PC Communication Protocol | Virtual COM port (RS232 style text commands) |
| PC operating system | Windows 7, Windows 8 |
| Power and Environment | |
| Power Supply Voltage | DC +5V |
| Power Consumption | 1.5 W |
| Operating Temperature Range | 0 °C - 50 °C |
| Non-Operating Temperature Range | -20 °C - 70 °C |
| Humidity Range | ≤80% Relative Humidity |
| Mechanical Dimensions (L x W x H) | 108 mm x 70 mm x 11 mm |
| Net Weight | 90 g |
| | |

Chapter 1: Product Introduction

Thank you for buying a SCI AWG2300 multifunction arbitrary waveform generator!

Before you start installing the instrument, check the items in your package with the list below.

1.1. Package contents

Check your package for following items.

| STANDARD | |
|--------------------|--|
| Instrument | AWG2300 arbitrary waveform generator |
| Cables | 1x USB 2.0 Type A to Mini-B Cable 10 Feet |
| Installation media | SCI AWG software disk (USB flash drive) |
| OPTIONAL | |
| Accessories | AWG2300-SIG signal expansion board |
| Hardware | 4x M2.5 stand-off screws; 4x M2.5 button head screws |
| Cables | 1x 20 pin flat cable; 1x 26 pin flat cable |
| Power supply | +5V DC power supply |

1-2. General Descriptions

AWG2300 is a dual-channel, 14 bit, 300MS/s simultaneously sampling arbitrary waveform generator capable of generating waveforms from DC to 50MHz. The maximum output voltage is 7Vpp when driving 1M Ohm load, and 3.5Vpp when driving 50 Ohm load. When connected to a PC via a standard USB cable, the AWG appears as a virtual RS232 COM port that can accept data and instructions from the PC. Various waveform parameters including the frequency, amplitude, offset and phase of the output waveform are adjustable by the AWG control software running on the PC. The designed waveform data is downloaded to the AWG via the USB cable by the same control software. After being programmed, the AWG can run on a +5V DC power supply without the PC in stand-alone mode, or remain USB powered.

In addition to the two fast waveform output and synchronization channels, AWG2300 also provides 8 analog input channels, 8 digital IO channels, and 4 analog control voltage output channels. All the user accessible signals are available on the three SMA connectors and two box-type extension connectors. The 8 digital IO channels can be configured individually as input or output, or be accessed as a group (1 byte). The analog input voltages across 8 analog input channels are measured at software controlled sampling rate. The 4 analog output channels generate analog control voltages at software defined values from OV to 4.096V.



Product left, top and right views. Connectors and indicators are: (1) SYNC, (2) User Extension A, (3)CH A, (4) CH B, (5) DC 5V power input, (6) User Extension B, (7) LED indicator, and (8) USB.

1-3. Connectors and Indicators:

1. **SYNC**: The synchronization signal of generated waveforms that are present on channel A and channel B simultaneously. This signal uses a SMA female type connector and the output has a voltage swing from 0V to 2V when driving a 50 Ohm load, and from 0V to 4V when driving a 1MOhm load. The bandwidth of this signal is from DC to 50 MHz.

2. User Extension A: This connector provides some extension signals to the user, including the 4 analog control voltage output signals and the counted trigger output signal. For detailed information on the pin map and individual signal descriptions, please see section 1-2.

3. **CH A**: The waveform output for channel A. This signal uses a SMA female type connector and the output has a voltage swing from 0V to 3.5V when driving a 50 Ohm load, and from 0V to 7.0V when driving a 1MOhm load. The bandwidth of this signal is from DC to 50 MHz.

4. CH B: The waveform output for channel B. Other properties of this signal is the same as CH A.

5. **DC 5V**: The connector for an external 5V (> 500 mA) power supply with a 0.9 mm ID, 3.2 mm OD plug connector.

6. **User Extension B**: This 20-pin, 1.27 mm pitch box header connector provides additional extension signals to the user, including the 8 digital IO signals and the 8 analog input signals. For detailed information on the pin map and individual signal descriptions, please see chapter 1-3.

7. **LED indicator**: This three color (red, green and orange) LED provides device connection and status information to the user. When the instrument is powered by the USB cable, the orange LED blinks for two times and the green LED become steady on; When the instrument is powered by an external 5V power supply, the orange LED blinks for two times and the orange LED become steady on.

8. **USB**: This USB (mini B) connector provides the connection from PC to the AWG device. The AWG can also be powered by this USB cable. Various parameters of the AWG can be controlled and programmed using a control software running on the PC.

1-4. User Extension Connector A

The User Extension Connector A is a 1.27 mm pitch, 26-pin box header type connector. The connector pin map is shown below. There are 4 channels of analog output signals (AOO - AO3) available on this connector, and each channel is capable of generating control voltages between OV and 4.096V, at software controlled update rate. This connector also provides 12 PFIO lines connected to the on-board FPGA chip controlling the waveform generation. PFIO_0 line is currently used as the counted trigger output. Other PFIO lines are reserved for future high speed logic and synchronization functions. Please see section 3-5 for application examples of the analog output signals.



| | | 2x13 | |
|---------|----|--|--------------|
| CND | 1 | 1 2 | 2 |
| PFIO 0 | 3 | $\begin{bmatrix} 1 & 2 \\ 2 & 4 \end{bmatrix}$ | 4 PFIO_1 GND |
| PFIO 2 | 5 | 5 6 | 6 PFIO_3 |
| PFIO 4 | 7 | | 8 PFIO_5 |
| CND 1 | 9 | 0 10 | 10 N CND |
| PFIO 6 | 11 | 11 12 | 12 PFIO_7 |
| PFIO 8 | 13 | 11 12 12 14 | 14 PFIO_9 |
| PFIO 10 | 15 | 15 14 | 16 PFIO_11 |
| 5V | 17 | 17 18 | 18 5V |
| AO0 | 19 | 10 20 | 20 |
| AO1 | 21 | 21 22 | 22 |
| AO2 | 23 | 21 22 23 24 | 24 |
| AO3 | 25 | 25 24 | 26 SND |
| | | 25 20 | - UND |

1-5. User Extension Connector B

The User Extension Connector B is a 1.27 mm pitch, 20-pin box header type connector. The connector pin map is shown below. This connector provides 8 digital IO (DIO) lines and 8 analog input (AI) channels. The 8 digital IO lines can be programmed individually as input or output, or be accessed together as one byte, at software controlled update rate. The voltage level of the DIO lines is between 0V and 3.3V. The 8 analog input channels can sample external input voltages between 0V and 3.3V, at software controlled sampling rate. Please see section 3-3 and 3-4 for application examples of these analog input and digital IO signals.



Chapter 2: PC installation

| Minimum | Recommended |
|----------------------------|--|
| Windows 7 | Windows 7 (64 bit) |
| High-performance dual core | Intel Core I3/5/7 series |
| CPU or quad core CPU | |
| 2 GB | 4 GB |
| 800 x 600 pixels | 1024 x 768 pixels |
| USB 2.0 | USB 2.0 |
| 20 GB | 40 GB |
| | MinimumWindows 7High-performance dual coreCPU or quad core CPU2 GB800 x 600 pixelsUSB 2.020 GB |

2-1. PC Requirements

2-2. PC Installation Steps

1. Install the "SCI AWG" software onto your PC using the provided USB disk drive. See section 2-3 for detailed steps of software installation. The software program icon with the name "SCI AWG" will be placed on the Windows desktop on your PC.

2. Connect the AWG2300 to a PC USB port using the provided USB cable. Configure the driver for AWG2300 following the steps described in section 2-4.

3. Launch the "SCI AWG" program on your PC desktop to test AWG2300 functions.

2-3. "SCI AWG" Software Installation

The following screens show the steps to install the "SCI AWG" on a PC with Windows 7 (64 bit) operating system.

1. Launch the "Setup.exe" from the "SCI AWG" folder on the provided USB thumb drive.



2. Click "Accept" button to install "Microsoft .NET framework" if it has not been installed on this PC.

| 5 SCI AWG Setup | | |
|---|--|------------|
| For the following com | ponents: | |
| Microsoft .NET F | ramework 4 Client Profile (x86 and x64) | |
| Please read the follow of the agreement. | ving license agreement. Press the page down key to se | ee the res |
| · · | | - |
| | | |
| | | |
| MICROSO | FT SOFTWARE | |
| MICROSO | FT SOFTWARE ENTAL LICENSE TERMS | |
| | FT SOFTWARE ENTAL LICENSE TERMS | 0.57 |
| MICROSO SUPPLEME MICROSOFT WINDOWS O | FT SOFTWARE ENTAL LICENSE TERMS .NET FRAMEWORK 4 FOR MICROS PERATING SYSTEM | OFT |
| MICROSO SUPPLEME MICROSOFT WINDOWS O | FT SOFTWARE ENTAL LICENSE TERMS .NET FRAMEWORK 4 FOR MICROS PERATING SYSTEM | OFT |
| MICROSO SUPPLEME MICROSOFT WINDOWS O | FT SOFTWARE ENTAL LICENSE TERMS .NET FRAMEWORK 4 FOR MICROS PERATING SYSTEM | OFT |
| MICROSO SUPPLEME MICROSOFT WINDOWS O | FT SOFTWARE ENTAL LICENSE TERMS .NET FRAMEWORK 4 FOR MICROS PERATING SYSTEM or printing e terms of the pending License Agreement? | OFT |
| MICROSO SUPPLEME MICROSOFT WINDOWS O | FT SOFTWARE ENTAL LICENSE TERMS .NET FRAMEWORK 4 FOR MICROS PERATING SYSTEM or printing te terms of the pending License Agreement? | OFT |
| MICROSO SUPPLEME MICROSOFT WINDOWS O | FT SOFTWARE ENTAL LICENSE TERMS .NET FRAMEWORK 4 FOR MICROS PERATING SYSTEM or printing te terms of the pending License Agreement? Accept, install will close. To install you must accept this | OFT |

3. Click "Next".



4. Click "Next".



5. Click "Next".



6. Wait a few seconds when the software is being installed.

| 😸 SCI AWG | | |
|-----------------------------|-----------------------|--------|
| Installing SCI AWG | | |
| SCI AWG is being installed. | | |
| Please wait | | |
| (| Cancel < <u>B</u> ack | Next > |

7. When following dialog appears, click "Yes".

| 😗 Use | r Account Control | |
|-------|---|---|
| 0 | Do you want unknown puł | to allow the following program from an plisher to make changes to this computer? |
| | Program name: Publisher: File origin: | D:\SCI AWG\SCI AWG.msi Unknown Hard drive on this computer |
| 💌 s | how <u>d</u> etails | <u>Y</u> es <u>N</u> o |
| | | Change when these notifications appear |

8. Click "Close".



9. A software program icon named "SCI AWG" will be placed on the windows desktop. This is the software program to control the AWG2300 from the PC.



The next steps, as described in section 2-4, are to install the USB communication port driver for AWG2300 to be recognized by the PC.

2-4. Driver Software Installation

Section 2-3 shows the necessary steps to install the AWG control software "SCI AWG" on the PC. When the AWG2300 is connected to the PC using a USB cable, only for the first time use, it requires a software driver file or a hardware information file (*.inf) being registered with the Windows operating system.

After installation of "SCI AWG" software, the following screen shots show the steps to register hardware information file "SCIUSBCOM.inf" on the same PC for the AWG2300 to work properly.

1. When it is the first time for the PC to connect to the AWG2300, the PC may be able to recognize the AWG2300 as a USB communication port automatically. In the example below a PC assigned COM3 to the AWG2300 automatically. If this is the case please skip all steps from 2 to 9 below which deal with un-successful automatic driver installation.



2. Depending on the drivers already installed on the PC, some PCs are not be able to recognize the AWG2300 as a USB communication port automatically. In this case a message will shown on the bottom right of the screen.



3. Please open "Control Panel" -> "System and Security" -> "System". Click the first item "Device Manager" on the left panel of the window.



4. The AWG2300 is shown as "CDC RS-232 Emulation Demo". Right click the item and choose "Update Driver Software ...".



5. When the following dialog shows up, click "Browse my computer for driver software".



6. Click "Browse.." button to select the installation folder for the "SCI AWG" software. The default path is "C:\Program Files\SciCore Instruments". Please make sure the check box "Include subfolders" is checked. Click "Next".



7. When the following dialog is shown, please clock "Install this driver software anyway".



8. After a few seconds, a message box is shown indicating that driver software installation is successful. Click "Close".

| | × |
|--|-------|
| 😡 📱 Update Driver Software - USB Communications Port (COM3) | |
| | |
| Windows has successfully updated your driver software | |
| | |
| Windows has finished installing the driver software for this device: | |
| USB Communications Port | |
| No. Contraction of the second se | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | Close |
| | |

9. The AWG2300 connected to the PC now shows in the Device Manager as "USB Communication Port (COMx)". The actual number assigned to the device depends on the number of communication ports already exist in this PC. In this example "COM8" is assigned to this particular AWG2300 connected to this PC.



Chapter 3: AWG Functions

The AWG2300 can output two channels of waveform simultaneously, at fixed sampling rate of 300MS/s. The waveform of each channel is defined by 4096 data point with 14 bit D/A resolution.

3-1. Open Communication with AWG2300

1. After installing software and driver on the PC, the user can click the "SCI AWG" software icon on Windows desktop to start the AWG control software. Note the "Device Status" in the bottom status bar of the program shows a message of "Not connected" when software starts. Click the "COM port" drop-down menu to select the communication port that has been assigned to the AWG, and click the "Open" button.



2. After the user clicks the "Open" button, the AWG is connected with the control software, as shown in below. Note the status bar now shows "AWG connected". The waveform parameters are also updated in the "Waveform Generation" control panel.

| Water and the second and the second s | eform Generator | |
|--|--|---------------|
| Port: COM8 - Close | Waveform Generation Analog Input Digital IO Analog Output | |
| Command: wfmpm? 0 | Channel: CHA | Invert Output |
| dac?2 dac?3 wfmprm?0 | Amplitude (V): 3.000 ↓ Increment(Hz): 1 ↓ Offset (V): 0.000 ↓ 1 ↓< | Read WFM |
| Answer: 1 3 3.000 0.000 0.000 0.500 1000.000 2343 2 | Phase (deg.): 0.000 Trig Count: 2 Duty Cycle (%): 50.0 Progress: | Save WFM |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |
| 0 | Waveform Points | 3 |

The useful software controls are:

Port: COM8
Close
List of available communication port on this computer that can be

opened or closed.

| Command: wfmprm? 0 | | The latest command sent from the PC to the AWG |
|--|---|--|
| dac?2 dac?3 wfmprm?0 | * | List of the command history |
| Answer: | | |
| 1 3 3.000 0.000 0.000 0.500 1000.000 2343 2 | * | The newest answer received from the AWG. |

3-2. Arbitrary Waveform Generation

1. If the user click "Read WFM" button, the waveforms that are stored in the AWG are uploaded to the PC and displayed in the signal window. The control software user interface is shown in the left, and the AWG output signals monitored on an oscilloscope (not provided) is shown in the right.



2. The user is free to adjust the waveform parameters include amplitude, offset, phase and duty cycle of the waveform in the control software. For example, if the user select "CH B", and change its duty cycle from 50% to 10%, and then clicks the "Read WFM" button again, the screens of the control software and oscilloscope are shown below.



3. Please note that AWG2300 can generate three types of waveforms (sine, square, and triangle) internally. Other custom type waveform needs to be designed on the PC and downloaded to the AWG. This example shows how to download a pre-designed custom waveform to AWG2300.

After clicking the "WFM Type" drop-down menu, an "open file" dialog is shown to ask the user to select the pre-designed waveform file. For testing purpose please click "Sinc.wfm" file and then the "Open" button.

| Multifunction Arbitrary Wavef | orm Generator | Copen (| | | | | | x |
|-----------------------------------|--|----------------|-----------------------------|--|----------------------|-----------------|-------|---|
| Port: COM8 v Close | Waveform Generation Analog Input Digital IO Analog Output | SCI | AWG > WFMs | • | ∳ Search W | 'FMs | | P |
| Command: wfm? 8088 | Channel: CH B V Display V Enable Output Invert Output | Organize 🔻 Nev | v folder | | | • | | ? |
| wfm? 8072 wfm? 8080 | WFM Type: Inangle Frequency (Hz): 1.000.000 ÷ Ampltude (V): Single Increment(Hz): 1 ÷ Read WEM | 🔆 Favorites | Name | Date modified | Туре | Size | | |
| wfm / 8088 | Offset (V): Custom | 🔚 Libraries | ECG.wfm | 3/16/2014 1:55 PM 3/16/2014 1:55 PM | WFM File WFM File | | 25 KB | |
| Answer: 31 27 22 18 13 9 4 0 | Phase (deg.): 0.000 Trig Count: 2 🚔 Save WFM Duty Cycle (%): 10.0 💠 Processer | | | | | | | |
| - | inges. | Homegroup | | | | | | |
| | | Computer | | | | | | |
| | | SCIDISK (D:) | | | | | | |
| Λ | | 두 Network | | | | | | |
| | | | | | | | | |
| 0 | | | File <u>n</u> ame: Sinc.wfm | | ✓ Waveform | Data Files (*.w | /fm) | • |
| 0 Device Status: AWG connected | Waveform Points 3999 | | | | Open | | ancel | |
| | | | | | | | | |

The waveform will be loaded to the control software as shown in the left screen below. After the user click the "Write WFM" button, the custom waveform is updated as AWG CH B output signal as shown on the oscilloscope.



The useful software controls are:



To select available waveform output channel and its parameters to

be displayed in the software.

- 2. Display To enable/disable the display of this waveform channel signals in the software.
- 3. To enable/disable the output of this waveform channel in AWG output.
- 4. Invert Output To invert the polarity of the waveform in the AWG output.

| WFM Type: | Custom 🔻 |
|-----------|----------------------------|
| | Sine Square Triangle |
| | Custom |

5. Custom. To select the output waveform type for this channel. Please note the three standard waveform types "Sine", "Square" and "Triangle" can be generated by the AWG internally. If the user select "Custom" type then the waveform data file needs to be provided to download to AWG.

| Amplitude (V): | 3.000 | - |
|-----------------|-------|---|
| Offset (V): | 0.000 | - |
| Phase (deg.): | 0.000 | - |
| Duty Cycle (%): | 10.0 | |

6. To adjust the Amplitude, Offset, Phase and Duty cycle of the waveform in the AWG output. Please note that the "Duty cycle" parameter does not apply to "Sine" waveform type.

7. Frequency (Hz): 1,000.000 To adjust the frequency of the output waveform.

Valid range is from 0 Hz to 50 MHz.

8. Increment(Hz): 1 To change the frequency increment when the up and down buttons of the frequency control is adjusted.

9. Trig Count: 64 To change the number of triggers to counted in the counted trigger output (PFIO 1).

10. **Read WFM** To transfer a copy of the waveform data from the AWG to the PC and displayed in the signal window.

11. Write WFM To transfer a copy of the designed waveform data from the PC to the AWG.

12. Save WFM To save to waveform currently output from the AWG as its default waveform to output after a power cycling event.

13. Progress: The progress indicator when the waveform data is transferred between the PC and AWG.

3-3. Analog Input

1. Setup the test sine waveform to be generated by the AWG channel B. Recommended settings are shown as below. Click the "Read WFM" button to check the waveform currently output from the AWG.



2. Use a conductive wire to connect the AWG channel B output signal to one of the analog input channel available on the "user extension B" connector. In this example the AI2 analog input channel is used.



3. Go to the "Analog Input" tab, check the "Continuous" check box, and click "Update" button. The signals appearing on AI2 will show on the signal monitoring window.



4. Keep the analog input channel measuring and updating, the user can go to the "Waveform Generation" tab to change the source waveform parameters. For example change the channel B output waveform to triangle waveform with 90% duty cycle and half of previous amplitude. The signals acquired from the analog input channel AI2 will change accordingly.



5. By connecting the other waveform output channel (AWG channel A) to another analog input channel (AI 6), the user can monitor the two analog input channels at the same time.



The valid analog input voltage range is 0V to 3.3V. Input signals outside of this range will appear saturated. The sampling rate is controlled by software (software polling mode). Limited by the data transfer speed of the communication port, the approximate maximum sample rate for single channel is measured about 100 Samples/second.

The useful software controls are:

to be processed and displayed.



2. For each channel, the number of data points to display in the full window. The larger the number, the longer time of the acquired signals been displayed in the signal window.

3. Continuous When checked, the selected analog input channels are sampled and displayed continuously.

3-4. Digital Input / Output

AWG2300 supports digital IO in two operation modes, bit mode and byte mode. In the bit mode, all eight IO lines (IO0 to IO7) are configured as input or output individually. In the byte operation mode, all eight IO lines are configured as one byte and are accessed together.





2. Setup the test waveform to be generated by the AWG channel B. Please note that the two channels are 180 degrees out of phase.



3. Use one conductive wire to connect the AWG channel A output signal to digital IO channel 4 (Bit 4), and use another conductive wire to connect the AWG channel B output signal to digital IO channel 6 (Bit 6).



4. To test the digital IO in bit operation mode, go to "Digital IO" tab, check the "Continuous" check box, and click "Update" button. The two signals appear on the two digital input lines will show as below.



5. While Bit 4 and Bit 6 of the digital IO channels are configured as input, the user can change other digital IO channels as output by checking the IO direction check box for each channel. The value of each bit can be changed using the up-down button and appears on the output.



6. Click the "Byte Mode" check box to enable the digital IO in byte operation mode. The IO direction is input.

| | otrary waven | orm Genera | tor | | | | | | |
|--------------------|--------------|------------|------------|-----------|---------------|----------|--------|--------|-------|
| Port: COM14 - | Close | Waveform | Generation | Analog In | put Digital I | O Analog | Output | | |
| Command: | | | In/Out | Value | | In/Out | Value | | |
| dibyte? | | BIT 0: | V Out | 1 🌩 | BIT 4: | 🗆 In | 0 🌲 | Byte | Modej |
| dibyte? | * | BIT 1: | 🗸 🔽 Out | 1 🌲 | BIT 5: | 🗸 Out | 0 🌲 | | |
| dibyte? dibyte? | | BIT 2: | 🗸 🗸 🗸 | 1 🌲 | BIT 6: | 🗖 In | 1 🌲 | Value: | |
| | * | BIT 3: | V Out | 1 🜲 | BIT 7: | V Out | 0 | 16 | |
| Answer: | | Displ | ay Length: | | | | | | _ |
| 16 | ~ | 512 | ÷ | V | Continuous | Up | date | Stop | |
| | Ŧ | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |

7. Click the IO direction check box to change it from "In" to "Out", and change the value of the using the up-down button. All eight IO lines are configured as one byte and each line corresponds to one bit in the binary code of the byte value.



The useful software controls are:

1. BIT 5: Out O The check box defines this bit to be input or output. The up-down buttons set the value to be 0 or 1.

Display Length:

2. For each channel, the number of data points to display in the full window. The larger the number, the longer time of the IO signals been displayed in the signal window.

- 3. Continuous When checked, the digital IO signals are displayed continuously.
- 4. When checked, all digital IO lines (BIT 0 to BIT 7) are accessed as one byte.
- 5. Out This check box defines the IO direction to be input or output.
 - Value:

6.

The value of the byte when the digital IO is in input or output.

3-5. Analog Output

Go to "Analog Output" tab of the control software. Changing the value in the box will change the output voltage of each analog output channel accessible in the "user extension connector A". Please see section 1-3 for detailed pin map of the user connector to test the voltages.

| Multifunction Arbitrary Wa | veform Generator | |
|----------------------------|---|-------|
| Port: COM8 👻 Close | Waveform Generation Analog Input Digital IO Analog Output | |
| Command: | | |
| wfmprm? 0 | 40.0 J222 (AL 0.222)/ | |
| fwver? sn? wfmom2.0 | AO 1: 333 🔮 0.333 V | |
| winpin's u | AO 2: 444 😴 0.444 V | |
| Answer: | AO 3: 555 🜩 0.555 V | |
| 101.0000.0000.000 | | |
| 0.500 10000.000 2 | | About |
| | | |
| 0 | Time (See) | |
| U ANNO | Time (Sec) | |
| evice status: AWG connecte | a | |

3-6. Check Device Information

Go to "Analog Output" tab of the control software, and click the "About" button.



The information including model name, firmware version, and serial number of the instrument will show in the "About" dialog. The version information of the "SCI AWG" software is also shown.



If no instrument is connected to the PC, only the software version information is shown. Other information about the instrument is displayed as unknown.



Chapter 4: Programming Interface

4-1. Programming requirements

After successful installation of the AWG driver and control software "SCI AWG", all designed functions of the AWG2300 can be tested using "SCI AWG" to work properly, as described in Chapter 3.

When connected to the PC using a USB cable, the AWG2300 appears as a standard COM port (i.e. COM3).



4-2. Communication software example

The following example shows how to write a software program to communicate with the instrument in Microsoft Visual Studio 2010, after all the preparation steps mentioned in section 4-1 is done.

1. Click "New Project ..." in Visual Studio 2010. For demonstration purposes, the Visual Studio is configured in Visual Basic development environment.

2. When following dialog is shown, select the "Windows Form Application" as project template; give the project the name "TestAWG" and click the "OK" button.



3. In the Toolbox Panel, double click "Components -> SerialPort" to add "SerialPort1" to the project.



4. Rename "SerialPort1" to "SerialPort_AWG", and change the PortName to "COM3" or the actual port number appears on the user's computer.



5. Add a few standard controls of buttons and textboxes to the project.



6. Add a few lines of code to handle when the buttons are clicked.



7. Press "F5" key on the keyboard to start testing this small program.

8. After click the "open" button once, input the first test command "mdnm?" and then click the "Send" button, the program will receive a response from the AWG as "AWG 2300" in the textbox named "answers". The user need click "Close" button before close the program. Note the "mdnm?" command is used to inquiry the device model name from a pre-defined command set as described in section 4.3.



4.3 AWG command Set

The list below is the complete command set supported by the instrument via the USB COM port.

4.3.1 Get Device Model Name

| Description | Get device model name as string |
|----------------|--|
| Command | mdnm? |
| Parameters | none |
| Return Values | The string contains the model name of the device |
| Example | mdnm? |
| Example Answer | AWG 2300 |

4.3.2 Get Device Vendor Name

| Description | Get device vendor name as string |
|----------------|---|
| Command | vdnm? |
| Parameters | none |
| Return Values | The string contains the manufacturer's name |
| Example | vdnm? |
| Example Answer | SCI |

4.3.3 Get Waveform Channel Number

| Description | Get number of waveform output channels supported by the device |
|----------------|--|
| Command | wfmchnum? |
| Parameters | None |
| Return Values | The number of waveform channels on the device |
| Example | wfmchnum? |
| Example Answer | 2 |

4.3.4 Set Waveform Type

| Description | Set output waveform type for the specified channel | | |
|-------------|--|----------------------|--|
| Command | wfmtype= [value1] [value2] | | |
| Parameter | [value1] | [value2] | |
| Туре | Integer | Integer | |
| Range | 0: Channel A | 0: Sine waveform | |
| | 1: Channel B | 1: Square waveform | |
| | | 2: Triangle waveform | |

| | 3: Custom waveform | | | |
|----------------|--|--|--|--|
| Return Values | ОК | | | |
| Example | wfmtype= 1 2 (Set channel B to output triangle | | | |
| | wavelorm) | | | |
| Example Answer | OK | | | |

4.3.5 Set Waveform Frequency

| Description | Set output waveform frequency for all channels |
|----------------|--|
| Command | wfmfreq= [value1] |
| Parameter | [value1] |
| Туре | Single |
| Range | 0 - 50,000,000 |
| Return Values | ОК |
| Example | wfmfreq= 100,000 (Set waveform frequency to be |
| | 100kHz for all output channels) |
| Example Answer | OK |

4.3.6 Set Waveform Amplitude

| Description | Set output waveform amplitude (Vpp) for the specified channel | | |
|----------------|---|-----------|--|
| Command | wfmamp= [value1] [value2] | | |
| Parameter | [value1] | [value2] | |
| Туре | Integer | Single | |
| Range | 0: Channel A | 0 to 10.0 | |
| | 1: Channel B | | |
| | | | |
| Return Values | ОК | | |
| Example | wfmamp= 0 3.2 (Set channel A output waveform | | |
| | amplitude to be 3.2V) | | |
| Example Answer | OK | | |

4.3.7 Set Waveform Offset

| Description | Set output waveform offset for the specified channel | | | |
|---------------|--|-----------|--|--|
| Command | wfmoffset= [value1] [value2] | | | |
| Parameter | [value1] [value2] | | | |
| Туре | Integer | Single | | |
| Range | 0: Channel A | 0 to 10.0 | | |
| | 1: Channel B | | | |
| Return Values | ОК | | | |

| Example | wfmoffset= 0 1.1 (Set channel A output |
|----------------|--|
| | waveform offset to be 1.1V) |
| Example Answer | OK |

4.3.8 Set Waveform Phase

| Description | Set output waveform phase for the specified channel | | |
|----------------|---|------------------------|--|
| Command | wfmphase= [value1] [value2] | | |
| Parameter | [value1] [value2] | | |
| Туре | Integer | Single precision float | |
| Range | 0: Channel A | -360.0 to 360.0 | |
| | 1: Channel B | | |
| | | | |
| Return Values | ОК | | |
| Example | wfmphase= 0 45.0 (Set channel A output | | |
| | waveform phase to be 45 degrees) | | |
| Example Answer | OK | | |

4.3.9 Set Waveform Duty-cycle

| Description | Set output waveform duty-cycle for the specified channel | | |
|----------------|--|------------|--|
| Command | wfmduty= [value1] [value2] | | |
| Parameter | [value1] [value2] | | |
| Туре | Integer Single precision float | | |
| Range | 0: Channel A | 0 to 100.0 | |
| | 1: Channel B | | |
| | | | |
| Return Values | ОК | | |
| Example | wfmphase= 0 90.0 (Set channel A output | | |
| | waveform duty-cycle to be 90%) | | |
| Example Answer | OK | | |
| Note | Duty-cycle only applies to square and triangle | | |
| | waveform types. | | |

4.3.10 Enable/Disable Waveform Output

| Description | Enable or disable waveform output for the specified channel. When | |
|-------------|---|----------------|
| | a channel is disabled it will output | 0V DC voltage. |
| Command | wfmon= [value1] [value2] | |
| Parameter | [value1] | [value2] |
| Туре | Integer | Integer |

| Range | 0: Channel A | 0: output disabled |
|----------------|--------------------------|--------------------|
| | 1: Channel B | 1: output enabled |
| Return Values | ОК | |
| Example | wfmon= 1 0 (Disable char | nnel B output) |
| Example Answer | OK | |

4.3.11 Invert Waveform Output

| Description | Invert the voltage polarity of the waveform for the specified | |
|-------------|---|--|
| | channel. | |
| Command | wfminv= [value1] | |
| Parameter | [value1] | |
| Туре | Integer | |
| Range | 0: Channel A | |
| | 1: Channel B | |
| Example | wfminv= 0 (Invert the waveform for CH A) | |

4.3.12 Download Waveform Data To AWG

| Description | Download waveform data from the PC to the AWG at the specified | | |
|----------------|--|---------|--|
| | address. To reduce the data transfer overload, 8 data points are | | |
| | updated in one command. | | |
| Command | wfmdata= [address] [value1] [value2] [value3] | | |
| | [value4] [value5] [value6] [value7] [value8] | | |
| Parameter | [address] [value1] to [value8] | | |
| Туре | Integer | Integer | |
| Range | 0 to 3999: Channel A 0 to 16383 | | |
| | 4096 to 8095: Channel B | | |
| Example | wfmdata= 4096 0 1 2 3 4 5 6 7(Download the | | |
| | first eight waveform data for CH B) | | |
| Example Answer | OK | | |
| Note | The downloaded waveform data is not applied to the output until | | |
| | the "wfmupdate=" command is set | nt. | |

4.3.13 Update AWG Output

| Description | Update AWG output using the downloaded waveform data for the specified channel. After this command the new waveform will |
|-------------|--|
| Command | wfmupdate= [value1] |
| Parameter | [value1] |

| Туре | Integer |
|----------------|--|
| Range | 0: Channel A |
| | 1: Channel B |
| Example | wfmupdate= 1 (Update CH B output using the latest waveform |
| | data) |
| Example Answer | OK |

4.3.14 Read Waveform Parameters

| Description | Read the waveform parameters for the specified AWG channel. These parameters include amplitude, offset, phase, dutycycle, etc. | | |
|----------------|---|------------------------|------------------------|
| Command | wfmprm? [value1] | | |
| Parameter | [value1] | | |
| Туре | Integer | | |
| Range | 0: Channel A | | |
| | 1: Channel B | | |
| Answer | [value1] [value2 | 2] [value3] [valu | ue4] [value5] |
| | [value6] [value' | 7] [value8] | |
| Parameters | [value1] | [value2] | [value3] |
| Туре | Integer | Integer | Single precision float |
| Range | 0: output is disabled | 0: sine wave | The output voltage |
| | 1: output is enabled | 1: square wave | amplitude of the |
| | | 2: triangle wave | specified channel |
| | | 3: custom wave | |
| Parameters | [value4] | [value5] | [value6] |
| Туре | Single precision float | Single precision float | Single precision float |
| Range | The offset voltage of | The phase (in | The duty-cycle of the |
| | the specified channel | degrees) of the | specified channel |
| | | specified channel | |
| Parameters | [value7] | [value8] | |
| Туре | Single precision float | Integer | |
| Range | The frequency of the | The trigger counter | |
| | output waveform | number | |
| Example | wfmprm? 1 (Checl | king CH B paramet | cers) |
| Example Answer | 1 2 3.000 -0.500 90.000 0.200 200000.000 2 | | |
| | (CH B output is enabled, triangle wave at 200kHz, amplitude is 3.0V, | | |
| | offset is -0.5V, phase shift is 90 degree, duty cycle is 20%, and the | | |
| | trigger counter numbe | r is 2) | |

4.3.16 Write Trigger Counter

| Description | The number of the triggers to be counted as output on the PFIO 1 |
|-------------|--|
| | i |

| | pin on the user connector 1 |
|----------------|--|
| Command | wfmtrgcnt=[value1] |
| Parameter | [value1] |
| Туре | Integer |
| Range | 1 to 4095 |
| Example | wfmtrgcnt= 64 (every 64 triggers will be counted to output one |
| | pulse on PFIO 1 pin) |
| Example Answer | OK |

4.3.17 Save Waveform As Default

| Description | Save the current waveforms and parameters as default settings. The next time when the AWG is powered all default settings are applied. | |
|----------------|--|--|
| Command | wfmsave | |
| Parameter | None | |
| Return Value | OK: Operation is Successful | |
| | Err: Operation is Failed | |
| Example | wfmsave | |
| Example Answer | OK | |

4.3.18 Read Analog Input

| Description | Read the analog input voltage on the specified input AIO to AI7. |
|----------------|--|
| Command | ai? [value1] |
| Parameter | [value1] |
| Туре | Integer |
| Range | 0 to 7 corresponds to the analog input channel AI0 to AI7 |
| Return Value | [result1] |
| Туре | Single precision float |
| Range | 0 to 3.30 (0V to 3.3V) |
| Example | ai? 5 (read AI5) |
| Example return | 1.60 (1.6V) |

4.3.19 Read Digital Input

| Description | Read the specified digital input line DI0 to DI7. | |
|-------------|--|--|
| Command | di? [value1] | |
| Parameter | [value1] | |
| Туре | Integer | |
| Range | 0 to 7 corresponds to the digital input channel DI0 to DI7 | |
| Return | [result1] | |

| Туре | Integer |
|---------|---------|
| Range | 0 or 1 |
| Example | di? 3 |
| Return | 1 |

4.3.20 Write Digital Output

| Description | Write specified digital output line DO0 to DO7. | |
|----------------|---|----------|
| Command | do= [value1] [value2] | |
| Parameter | [value1] | [value2] |
| Туре | Integer | Integer |
| Range | 0 to 7 corresponds to DO0 to | 0 or 1 |
| | DO7 | |
| Example | do= 2 1 (output 1 on DO2 line) | |
| Example Answer | OK | |

4.3.19 Read Byte Digital Input

| Description | Read a byte from DI7 to DI0. | |
|-------------|--|--|
| Command | dibyte? | |
| Parameter | None | |
| Return | [result1] | |
| Туре | Integer | |
| Range | 0 to 255 | |
| Example | dibyte? | |
| Return | 128 (10000000 is read from DI7 to DI0) | |

4.3.20 Write Byte Digital Output

| Description | Write a byte to DO7 to DO0. | | |
|----------------|---|--|--|
| Command | dobyte= [value1] | | |
| Parameter | [value1] | | |
| Туре | Integer | | |
| Range | 0 to 255 | | |
| Example | dobyte= 128 (output 10000000 to D07 to D01) | | |
| Example Answer | OK | | |

4.3.21 Read Analog Output

| Description | Read the output voltage at the specified analog output channel AO0 | |
|----------------|--|--|
| | to AO4. | |
| Command | dac? [value1] | |
| Parameter | [value1] | |
| Туре | Integer | |
| Range | 0 to 3 corresponds to AO0 to AO3 | |
| Return Value | [result1] | |
| Туре | Integer | |
| Range | 0 to 4095 corresponds to 0V to 4.095V | |
| Example | dac? 1 | |
| Example Answer | OK | |

4.3.21 Write Analog Output

| Description | Write a new output voltage at the specified analog output channel | |
|----------------|---|--------------------------------|
| | AO0 to AO4. | |
| Command | dac= [value1] [value2] | |
| Parameter | [value1] | [value2] |
| Туре | Integer | Integer |
| Range | 0 to 3 corresponds to AO0 to | 0 to 4095 corresponds to 0V to |
| | AO3 | 4.095V |
| Example | dac= 2 2048 (output 2.048V on AO2) | |
| Example Answer | OK | |

4.3.22 Check Firmware Version

| Description | Write a new output voltage at the specified analog output channel |
|----------------|---|
| | AO0 to AO4. |
| Command | fwver? |
| Parameter | None |
| Return | [result1] |
| Туре | Single precision float |
| Example | fwver? |
| Example Answer | 1.1 |

Chapter 5: Signal Expansion Board

5-1. Signal Expansion Board

The AWG2300 only needs a USB cable or a 5V power supply to operate in stand-alone mode, and outputs the waveforms from the two SMA connectors. For convenient access of other signals including analog input, analog output and digital IO, a signal expansion board can be mounted on the AWG with two flat cables connections between the AWG and the signal expansion board.

5-2 Signal expansion board installation

1. Disconnect the USB and power cable from the AWG2300, remove the four flat-head screws on the top cover with a Phillips #1 screwdriver.

2. Using four M2.5 stand-off screws to secure the AWG2300 top cover to the base.

3. Using a 1.5 mm hex key screw driver to tighten four M2.5 button-head screws to mount the signal expansion board on the four stand-offs already installed in previous step.

4. Connect the signal expansion boardwith the AWG using a 20 pin flat cableconnector on one side and a 26 pin connector on the other side.





5-3. Available Signals

To connect a signal wire to a screw terminal, prepare the wire by stringing ~5mm of insulation, insert the wire into the screw terminal, and securely tightening the screws with a flathead screwdriver. The signals that can be accessed on the signal expansion board include:

| Signal type | Name | Location |
|-----------------------|----------------|-------------------------|
| Power signals | +5V | USER CON1 and USER CON2 |
| | +3.3V | USER CON3 and USER CON4 |
| | GND | All connectors |
| Analog input signals | AI 0 - AI 7 | USER CON4 |
| Digital IO signals | 10 0 - 10 7 | USER CON3 |
| Analog output signals | AO 0 - AO 3 | USER CON2 |
| Functional IO signals | FIO 0 - FIO 11 | USER CON1 and USER CON2 |



Chapter 6: Mechanic Drawings





62.50 63.50 65 3.06 0.90 0 2.04 0 1.50 2.50 0 ę CH B CHA TRIG € 4 AWG2300 10 Arbitrary Waveform Generator **[**5∨ 5V o 0000000000000 GND N.C N.C. FIO 10 D 3 GND FIO 8 GND GND FIO 1 FIO 6 FIO FIO 4 GND GND GND FIO 2 Ö 3.3 Al 7 Al 6 Al 5 000000 0000000000000 FIO 7 FIO 0 FIO 5 GND GND A00 GND Ō AO I FIO 3 C AO 2 D AI 3 FIO 1 0 0 03 Õ AI 2 GND 0 0 GND G USER CON1 USER CON2 GND USER CONS 86 93 96 USER CON4 Signal Expansion Board шшш œ USB DC 5V

6-2. Signal expansion board dimensions (All units are in mm)



Copyright © 2014 SciCore Instruments. All rights reserved.

SciCore Instruments Contact Information

SciCore Instruments, Inc.

87 Knob Hill Road

Hackettstown, New Jersey 07840, USA

Telephone: (908) 998-2514

E-mail: info@scicoreinstruments.com

Web site: www.scicoreinstruments.com

For comments and technical questions regarding AWG2300, send e-mail to:

support@scicoreinstruments.com